

Re Place wall STEPS

- ① Remove old broken concrete wall
- ② Complete over dig 6 FT behind wall for EROSION cloth and wall Retainer
- ③ Place $3/4$ trap rock and tamp 6-8 inches thick
- ④ Place EROSION cloth ON tamped trap rock
- ⑤ Place one layer of belgard block
- ⑥ back fill 1st layer of block
- ⑦ Place EROSION cloth
- ⑧ Place 2nd layer of block
- ⑨ Back fill to top of block
- ⑩ Place layer of EROSION cloth
- ⑪ install cap of wall and glue down cap of wall using zigged nails
- ⑫ Back fill to top of wall cap

RECEIVED
ENFIELD PLANNING DEPT.
2021 OCT 13 PM 12:08